



**SOL 100/140/170**

**2008**




**Reservedelsliste  
Spare parts list  
Ersatzteilliste  
Onderdelenlijst  
Liste de pièce de rechange  
Lista dei pezzi di ricambio**

# SOL 100





# SOL 100





# SOL 100





Fig.	New part No.	Old part No.	Description	From	To	Notes
1	#I/T	R003007490	COVER			
2	90220800060	R003001174	CONTROL BOX 552SE			
3	#I/T	R003007396	FUSE			
4	#I/T	R003006937	7 PIN PLUG			
5	#I/T	R003007491	COVER			
6	#I/T	R003007458	VIEWING PORT			
7	90220800096	R003007839	P.E. CELL			
8	#I/T	R003007493	TUBE			
9	#I/T	R003000443	JOINT			
10	#I/T	R003007494	BRACKET AND SCREW			
11	#I/T	R003007465	LEAD			
12	90220800081	R003007495	ELECTRODE ASSEMBLY			
13	#I/T	R003007475	SUCTION DUCT			
14	#I/T	R003007466	SUPPORT			
15	#I/T	R003007496	NOZZLE HOLDER			
16	90220800079	R003006978	DIFFUSER DISC			
17	#I/T	R003007485	COLLAR			
18	90220800065	R003005795	GASKET			
19	90220800066	R003005796	FRONT PIECE			
20	#I/T	R003007498	BLAST TUBE			
21	90220800082	R003007499	AIR DAMPER REGULATOR			
22	90220800097	R003007840	AIR DAMPER			
23	#I/T	R003007476	FAN			
24	90220800098	R003008489	MOTOR			
25	#I/T	R003007479	CAPACITOR			replaces R003007478 4 mF
26	90220800091	R003007771	PUMP			
27	#I/T	R003007772	LEAD			
28	#I/T	R003007565	COIL			
29	#I/T	R003007566	SHELL AND KNOB			
30	#I/T	R003007454	SOCKET			
31	90220800061	R003005720	FLEXIBLE OIL LINE			
32	#I/T	R003009068	CONNECTOR			
33	#I/T	R003007162	O RING			
34	#I/T	R003005719	FILTER			
35	#I/T	R003007087	SEAL			
36	#I/T	R003007268	CONNECTOR			
37	#I/T	R003000439	PUMP SEAL			
38	90220800087	R003007582	NEEDLE VALVE			
39	#I/T	R003007173	O RING			
40	#I/T	R003007156	O RING			
41	#I/T	R003007202	REGULATOR			
42	#I/T	R003007028	O RING			
	90220210009	9021088001000	NOZZLE			1.25 GPH 60° S







# SOL 140





# SOL 140






Fig.	New part No.	Old part No.	Description	From	To	Notes
1	#/T	R003002495	PUMP			
2	#/T	R003002451	COIL			
3	#/T	R003002496	LEAD			
4	#/T	R003002498	TUBE			
5	#/T	R003003081	SEAL			
6	#/T	R003003082	FILTER			
7	90220800060	R003001174	CONTROL BOX 552SE			
8	#/T	R003007396	FUSE			
9	#/T	R003006937	7 PIN PLUG			
10	#/T	R003007642	COVER			
11	#/T	R003007458	VIEWING PORT			
12	#/T	R003007857	P.E. CELL			
12	90220800096	R003007839	P.E. CELL			
13	#/T	R003000443	JOINT			
14	#/T	R003007644	BRACKET AND SCREW			
15	#/T	R003007651	SUCTION DUCT			
16	#/T	R003007466	SUPPORT			
17	90220800089	R003007645	DIFFUSER DISC			
18	#/T	R003007465	HIGH VOLTAGE LEAD			
19	90220800081	R003007495	ELECTRODE ASSEMBLY			
20	#/T	R003007646	COLLAR			
21	90220800070	R003005813	GASKET			
22	90220800071	R003005814	FLANGE			
23	#/T	R003007647	BLAST TUBE			
24	#/T	R003007648	AIR DAMPER REGULATOR			
24	#/T	R003002395	AIR DAMPER REGULATOR			
25	#/T	R003007650	AIR DAMPER			
25	#/T	R003002394	AIR DAMPER			
26	#/T	R003007496	NOZZLE HOLDER			
27	#/T	R003007652	FAN			
28	90220800099	R003008492	MOTOR			
29	90220800090	R003007655	CAPACITOR 6,3 mF			
30	#/T	R003007454	MOTOR SOCKET			
31	#/T	R003009068	CONNECTOR			
32	90220800061	R003005720	FLEXIBLE OIL LINE			
33	#/T	R003007641	COVER			
40	90220800091	R003007771	R.B.L. PUMP			
41	#/T	R003007162	O-RING			
42	#/T	R003005719	FILTER			
43	#/T	R003007087	SEAL			
44	#/T	R003007268	CONNECTOR			
45	#/T	R003007643	TUBE			
46	#/T	R003007772	LEAD			
47	#/T	R003000439	PUMP SEAL			
48	90220800087	R003007582	NEEDLE VALVE			
49	#/T	R003007565	COIL			
50	#/T	R003007566	SHELL AND KNOB			
51	#/T	R003007156	O-RING			
52	#/T	R003007173	O-RING			
53	#/T	R003007202	REGULATOR			
54	#/T	R003007028	O-RING			
	90220210028	9021088002900	NOZZLE			2.50 GPH 60° W

# SOL 170





# SOL 170







# SOL 170




Fig.	New part No.	Old part No.	Description	From	To	Notes
1	#N/D	R003007641	COVER			
2	#N/D	R003000439	PUMP SEAL			
3	#N/D	R003007028	O RING			
4	#N/D	R003007202	REGULATOR			
5	#N/D	R003007162	O RING			
6	#N/D	R003007156	O RING			
7	#N/D	R003007173	O RING			
8	#N/D	R003005719	FILTER			
9	90220800078	R003006925	NEEDLE VALVE			
9	90220800087	R003007582	NEEDLE VALVE			
10	#N/D	R003007203	PLATE			
11	#N/D	R003007029	O RING			
12	#N/D	R003007396	FUSE			
13	90220800060	R003001174	CONTROL BOX 552SE			
14	#N/D	R003006937	7 PIN PLUG			
15	#N/D	R003007454	PSOCKET (Motor)			
16	#N/D	R003007772	LEAD			
17	#N/D	R003007481	COIL			
17	#N/D	R003007565	COIL			
18	#N/D	R003000443	JOINT			
19	90220800075	R003006553	SHELL AND KNOB			
19	#N/D	R003007566	SHELL AND KNOB			
20	#N/D	R003007869	TUBE			
21	90220800099	R003008492	MOTOR			
22	#N/D	R003007642	COVER 1			
23	#N/D	R003007644	BRACKET AND SCREW			
24	#N/D	R003007458	VIEWING PORT			
25	#N/D	R003007857	P.E. CELL			
25	90220800096	R003007839	P.E. CELL			
26	#N/D	R003007651	SUCTION DUCT			
27	#N/D	R003007496	NOZZLE HOLDER			
28	#N/D	R003007466	SUPPORT			
29	90220800089	R003007645	DIFFUSER DISC 4			
30	#N/D	R003007465	HIGH VOLTAGE LEAD			
31	90220800081	R003007495	ELECTRODE ASSEMBLY			
32	90220800168	R003007646	COLLAR			
33	90220800171	R003007868	BLAST TUBE			
34	90220800070	R003005813	GASKET			
35	90220800071	R003005814	FLANGE			
36	#N/D	R003007648	AIR DAMPER REGULATOR			
37	90220800170	R003007650	AIR DAMPER			
38	#N/D	R003007652	FAN			
39	#N/D	R003008567	AIR DAMPER REGULATOR			
40	90220800092	R003007784	HYDRAULIC JACK			
41	#N/D	R003007783	TUBE			
42	#N/D	R003007870	HYDRAULIC DELAYNG DEVICE			
43	90220800090	R003007655	CAPACITOR			6.3 mF
44	#N/D	R003007780	TUBE			
45	#N/D	R003007788	TUBE			
46	#N/D	R003007854	PUMP			
46	90220800094	R003007809	PUMP			
47	#N/D	R003007079	SEAL			
48	#N/D	R003005805	CONNECTOR			
49	#N/D	R003005804	PIN			
50	90220800061	R003005720	FLEXIBLE OIL LINE			
51	#N/D	R003009068	CONNECTOR			
52	#N/D	R003005801	SEAL			
	90220210012	9021088001300	NOZZLE			3.50 GPH 60° S

